


RESET PASSWORD

- Pull out bolt knob slide to second stop position and push down to lock
- 2. Rotate wheels to chosen number combination
- 3. Pull back bolt knob



INSTALLATION DRAWING

